

# Translations:Poële de chauffage de tente/11/en

---

Cut at least 3 small pieces of wire and bend them through the net. You have to be in the double layer part. The end of the hook has to face up.