## Translations:Bélier hydraulique/133/en



For both techniques, it is really important to put the threaded rod at the center of the system, otherwise it would get stuck and block the whole system.