

Translations: Bassin de culture de spiruline/11/en

For ergonomics, it is necessary to adjust the height of the basin to the worker's size. The basin is 30 centimeters high. In our case the bottom of the basin is one meter above the ground. When calculating the height of the legs, the thickness of the low and high frames must also be taken into account.

- Make 4 legs with half-rafters,
- Place the corner legs aligned with the corners of the bottom frame,
- Install four central legs, of a single half-rafter, facing each stiffener of the low frame,
- Place a bracket about 30 cm between each center leg and its bottom frame stiffener, four in total.