

Translations:Biodiesel/83/en

- Stir and let the catalyst dissolve completely in the methanol. This takes roughly 2 minutes. And once again, be careful: the blend deteriorates quickly. Carry on with the next stage as soon as the catalyst/methanol blend is homogeneous.