

# Translations:Biodiesel/89/en

---

-Slowly add the washing solution representing the equivalent of 20% the volume of biodiesel, to avoid the formation of soap and wait 10 minutes. Drain off the washing water.