

# Translations:Brumisateur/15/en

---

The PVC tube must be cut so as to guide the mist. The PVC tube is then inserted into the box, it takes support on the bottom of the box.