

Translations:Chauffage solaire version ardoise/73/en

- Prepare an area of 1m x 2m for the chosen background (here a 10mm thick film plywood).
- Prepare a surface of 1m x 2m for the chosen insulation (here STEICO plates of 22mm thickness).
- Pull a wood glue seal on the frame battens, 32mm thick side.
- Deposit '*the bottom first*' then ensure the plating with regular studding.
- Draw sika cords on the bottom then lay the insulation. This is the outermost layer of the frame.