

Translations:Chauffage solaire version ardoise/87/en

- Position the first slate rack on the lowest level of baffle.
- Mark 2 holes and drill with a 4mm drill. It is possible to slightly mill the holes with a wider drill so that the screw head is integrated in the thickness of the slate.
- If necessary, cut the slates with the diamond disc grinder, a hacksaw can possibly do the trick.
- Complete the slate frame, taking care to raise the slates on the baffles closest to the exit (see photo).

Note: The row of slate is raised near the exit so that the air in front of and behind the slates can be evacuated, both in winter and in summer by the "summer hatch".