

Translations:Chauffage solaire version ardoise/91/en

Note: Here, a tempered glass 6mm thick is used. It is also possible to use polycarbonate.

- Clean the glass.
- Prepare the beading in the rest of battens of 53mm x 20mm. A chamfer is made for a good water evacuation and a 45 ° cut as for the frame. Oil and varnish the screens.

'Note:' The baffles are used to hold the glass in its housing by compressing the compression joint. They must both cover the edge of the glass and rest on the frame.

- Pull a silicone gasket between the compression seal and the frame.
- Position the glass.
- Pull a silicone seal again on the edge of the glass as well as on the frame.
- Position and screw the baffles.
- Pull a silicone bead on the glass edge / beading