

# Translations:Chauffe-eau solaire/22/en

---

Start by passing the tubes in the chambers created before, and cutting them in way that when you slot the T in the tube, the neck of the bottle be almost in contact with the T.