

Translations:Chauffe-eau solaire/23/en

Stick the T on the tubes (the chamber around the tube) then use adhesive tape to fix the bottle between them, and the necks at the end of the T pipes.