

Translations:Chauffe-eau solaire/26/en

Frost with sand paper with thin grain the part you have to assembling.

Clean it with a rag soak in stripper.

Apply the glue at the entry of the female part and on the whole male part.

Slot immediately completely, without twist.

Clean the glue drip.