

Translations:Chauffe-eau solaire à thermosiphon/30/en

- Cut the copper pipes coming out of the frame leaving 2-3cm.
- Attach a silicone or latex tube to each of the outlets using hose clamps. Make sure that the connection is airtight by blowing into the silicone/latex tubes when the circuit is filled with water, for example.