

Translations:Cuiseur micro gazéificateur/19/en-gb

- then drill where marked using a 12mm drill bit (or with a hammer and nail) (For a cleaner finish, we recommend that you make pilot holes with a 7mm drill bit before tackling it with a 12mm drill bit).