

Translations:Cuisinière améliorée - Modèle Patsari/42/en

- Pour two buckets of soil mortar at the location of the secondary hotplates.
- Insert the molds at the hotplate sites. You could use two plastic bowls of the same diameter as the hotplates + two pieces of wood instead of molds.
- Make sure the hotplates are level with the edges of the stove.