

Translations:Elevage de Mouches Soldats Noires/109/en

- With a saw, cut the cleats and board to the right dimensions
- With screws, fix the 4 cleats of 80cm to the 4 corners of the board. Make sure they are all in the same direction.
- With screws, fix a 41cm cleat between two vertical cleats. Put its smallest side vertically, its width should perfectly fit the vertical cleats. It must be at the highest level, in the continuity of the vertical cleats.
- With screws, fix the second 41cm cleat.
- With angles, fix a 40cm strip between two vertical cleats. Put its smallest side horizontally. Its width should perfectly fit the vertical cleats. It must be at the highest level; in the continuity of the vertical cleats.
- Attach the second 40cm cleat.