

Translations:Eolienne 200W/142/en

- Drill the center of the cradle with a small drill (approx 3mm). This drilling will be used when the stator is cast.