

Translations:Eolienne 200W/155/en

- After completing the metal “base” structure of the coiler, cut out both ears and the spacer as shown. Make with drills with precision. Cut a small notch on one of the two ears to catch the copper wire while winding it.