

# Translations:Eolienne 200W/161/en

---

- Before unmolding, seal the coil with an electrical tape. A ruler can be use to pass the tape between the spacer and the coil, with the help of the large slots on the ears which were created for this purpose.