

# Translations:Eolienne 200W/175/en

---

- Solder the connections with a soldering iron. For a good solder, heat the area to be soldered then put the tin on the wire so that it melts and fills the gaps.