

Translations:Eolienne 200W/179/en

- Solder de the ends of the coil 4,5, and 6 forming the 3 phases then protect them with the heat shrinking sleeves. Special attention need to paid to the insulation, the wires can touch each other.