

# Translations:Eolienne 200W/185/en

---

**Notes:** This step includes use of dangerous elements (resin, fibers, etc. ) Make sure to put on the latex gloves and safety glasses till the end of the molding.