

Translations:Eolienne 200W/187/en

- Prepare the 3 threaded rods by screwing them on the cradle. Adjust the parallelism of the rod well.