• Place the mounting of the coil in the mold carefully. Every coil must be placed correctly in its place and no wire should come out of the mold. It's a delicate step. Pour the first container of resin completely.