

Translations:Eolienne 200W/205/en

Allow to harden (it might take several hours). Then demold, deburr and varnish or paint.