

# Translations:Eolienne 200W/258/en

---

- Solder the cradle at the end of the angle by centering the center of the cradle on the point A. For the soldering, it is necessary to sacrifice one of the four holes allowing the fixation of the spindle. It is not a problem though since all the other holes are very well accessible.