

Translations:Four à économie de bois/15/en

- Mix the soil (clay soil if possible) with water in a big bucket.
- Mix well.
- Cover the arch with the fine wire mesh once the correct shape has been given.
- Make sure you leave the 10 cm hole in the arch free, for the flue
- ,
- Cover the wire mesh with a 4 cm layer of mud without covering up the 10 cm hole.
- Leave to dry.