

Translations:Four à économie de bois/21/en

Once the soil is completely dry :

- Start a fire up in the fireplace. Maintain it sufficiently.
- Wait until the oven is really hot, a suitable thermometer can be placed inside to check the temperature. This can take between 30 and 40 minutes.
- Place the dish(es) in the oven and keep an eye on the baking process by quickly opening the oven door. Carry on maintaining the fire as normal.