

Translations:Hydroponie/46/en

- At the bottom of the first tank, drill a hole with the hole saw of the diameter of your outlet pipe to the second tank.
- Install the nozzle and hose on the tank
- Spread a layer of coarse gravel on the bottom (1/4 of the filter volume)
- Add a layer of clay beads of the same thickness
- Add a slightly thinner layer of sand on top
- Install the filter under the water pocket at the outlet of the gutter, and raise it above the biofilter to allow the water to flow by gravity.