

Translations:L'énergie dans l'habitat/40/en

It is also important to pay attention to heat bridges, which are weak zones in the building envelope. In these areas, exterior cold is transmitted more rapidly into the interior of a home. The most significant heat bridges are found at junctions between the roof and the walls and between walls and window woodwork. These are the primary areas that should be insulated.