1 - Screw the blades (cut out in step 3) to their base (cut out in step 4).