

Translations:Lampe solaire à batteries lithium récupérées/281/en

- Place the panel on the bigger board, mark the position of the + and - outputs of the pannel and drill a hole of 5mm in both boards. (If any component is already in this place, the hole should be moved).