

# Translations:Le biofiltre/48/en

---

1) Drill 7 or 8 small holes in the bottom of one of the 60L vats using the drill.