

Translations:Le biofiltre/57/en

2) Drill a few smaller holes at the bottom of the basin. They will permit for the liquid to go from the basin to the vat.