Translations: Matelas low-tech/43/fr

- Apply pressure with the piece of wood on the can to finalize the weld for about 30 seconds