

Translations:Meuble lavabo autonome/15/en

1. Plot the outline of the part of the sink to be inserted on the non-visible side of the board (the underside).
2. Drill a hole on each of the 4 corners of the outline
3. Cut out the outline with the jigsaw
4. Insert the sink
5. Install the shelf with the sink at the desired height according to the size of the children or adults



...Using masking tape to make the pencil outline can allow you to bypass making marks on the wood.