


Translations:Meuble lavabo autonome/20/en

1. Mark the location of the fitting on the lowest end of the bucket.
2. Drill the bucket with the step drill bit.
3. Screw the fitting in. Attach the gasket and nut to the fitting inside the bucket.

Be careful to leave enough space for the nut which is bigger than the fitting.