

# Translations:Meuble lavabo autonome/34/en

---

1. Mark the location and drill a hole using a size 18 flat wood bit
2. Make a countersink hole using a size 39 flat wood bit on the bottom of the board.
3. Screw the base of the tap into the board and install the spout.