


Translations:Meuble lavabo autonome/44/en

1. Drill a 32mm hole into the lid of the jerrycan with the flat drill bit and drill.
2. Connect the sink drain to the jerrycan.
3. Install a 40mm diameter PVC fastener for the drainage hose. "(When the jerrycan is full and it's time to empty it, this fastener allows you to keep the hose raised, which prevents the water remaining in the hose from spilling on the floor, which happened on our first use...)"
4. Install and test the drainage system.

 ...Put a Colson hose clamp (zip tie) on the ribbed hose on the interior of the jerrycan. This stops the children from removing the drainage hose from the water.