


Translations:Meuble lavabo autonome/49/en

1. Trace and then cut out the outlines of the feet of the shelf by drilling then cutting the portions out with a jigsaw.
2. Fix the board to the shelf with two flat angle brackets.

 ...To be permanently attached after having fixed the foot pump in place.