

# Translations:Phytoépuration eaux usées/144/en

---

In order for the sanitation to be entirely self-sufficient and to consume no energy, we use gravity to power the two filters. The top of the vertical filter, then, must be lower than the point of collection of wastewater from the house. Likewise, the top of the horizontal filter must be lower than the bottom of the vertical filter. The installation will therefore probably take place on the lowest part of the garden. If this is not possible due to flat terrain, a condensate pump can be installed between the point of collection and the vertical filter, the latter being above ground and the horizontal filter respectively being underground.