

# Translations:Phytoépuration eaux usées/160/en

---

Install a slotted drainpipe at the bottom of the filter with a T leading to the pass-through fitting.