

# Translations:Poelito - Poêle de masse semi-démontable/170/en-gb

---

It is better to scour down the drum before starting construction. In all cases, this should be done before lighting the first fire as this will blister the paintwork which is not designed for resisting high temperatures. The simplest way to scour it down is by using abrasive discs on a grinding machine. It is also possible to use a sander or attach a wire brush to a drill.