

Translations:Poelito - Poêle de masse semi-démontable/194/en-gb

Insulating Mix:

- Calculate the volume needed for the insulating <https://drive.google.com/file/d/1vtasWBKad9EEFBpeoNq38jT7SOasalra/view>
- Make up the mix referring to the instructions on how to make up the insulating mix and what goes in it Step X.
- Pour the insulating mix up to the 3cm mark.
- As you are doing this, pack down the mix using a tamper .
- Ensure the wires which hold in the moulds are sticking out.
- Wait two hours until the first layer is surface-dry so that you can then pour on the dense mix.