

Translations:Poelito - Poêle de masse semi-démontable/197/en-gb

- Calculate the volume needed for the dense mix <https://drive.google.com/file/d/1vtasWBKad9EEFBpeoNq38jT7SOasalra/view>
- Make up the mix referring to the instructions on how to make up the dense mix and what goes in it in Step X.
- Pour in the 3cm of the dense mix up to the 6cm mark.
- As you are doing this, pack down the mix using a tamper .
- Ensure the wires which hold in the moulds are sticking out.
- Wait 24 hours before pouring the remainder.