

Translations:Poelito - Poêle de masse semi-démontable/210/en-gb

Removing the moulds can be done 12 hours after pouring the concrete. This can be quite a tedious task.

- Use gloves to avoid damage to hands from the concrete when poking them into the holes.
- Pull out all that you are able to retrieve from the orifices either by hand or with a pair of pliers.
- Once you have taken out as much as you can, light a fire in the hole to burn off and get rid of that which is left inside.
- Use methylated spirits to facilitate the process of burning the bits you want to get out . However, care must be taken to never put alcohol onto the fire. When the fire gets going, use little pieces of dry wood to keep the fire burning.