

# Translations:Poelito - Poêle de masse semi-démontable/213/en-gb

---

- Take the length between the level of the concrete and the top of the barrel, add 15mm for the fins and whatever the height of the stopper is. The top of the tube has to have a male fitting in so you can fit a stopper onto it.
- Cut out the tube.
- Make 15mm high fins every centimetre on the lower part.
- Fold back every other fin towards the outside.