

# Translations:Poelito - Poêle de masse semi-démontable/223/en-gb

---

- Cut the outside cardboard tube.
- Cover the inside surface in plastic.
- Cut the inside cardboard tube.
- Cover the outside surface in plastic.
- Cut out two rings from cardboard. These will be used as spacers between the inside and the outside tubes.
- Cover them in plastic.
- Put the spacers at the bottom to close up the mould.
- Fill with the insulating mix (fire cement and vermiculite) a bit at a time.
- Spread the mix out and pack down tightly with a small tamper.