

# Translations:Point d'eau économe et autonome/28/en

---

- Position the level on the top leaving the space of a child's hand. Mark and drill 2 small holes in the lever at the height of the nail.
- Screw the lever on the corner of the wooden box and insert the iron wire in the holes. Twist the ends of the iron wire around the nail. (NB: The iron wire must be tensed).