

# Translations:Point d'eau économe et autonome/30/en

---

- Cut the bottom of the bottle. Drill its cap to a diameter slightly inferior than the hose. Insert the hose through and let it go a centimeter beyond the cap.
- Position the bottle on the batten over the lever. Adjust the length of the hose.
- Attach the bottle with 2 iron wires, blocked by 4 screws.
- Let the hose go below the nail and keep it on the side of the plank with a staple. Put the elastic in place (around the nail and screw) and set its tension such as the hose is pinched.